

Dive Light Rentals



When renting out Dive Lights make sure of the following:

Insert a battery (Positive up) into the Light Body,
Insert the Lamp Head and screw on the Lense Cap.
Make sure the fit is tight as you screw on the cap.
Tighten all the way till the light comes on.
Then turn back about half a turn to shut off the light.

Explain to the customer how to turn on and off the light.

Tell them not to remove the Lense Cap.

Inform the customer that there will be a \$20 service fee if the light comes back flooded.

Note the light rental on the rental form.

When the customer returns with the Dive Light:

Check that the light will turn on by twisting the Lense Cap closed.

If it does not come on then unscrew the Lense Cap and check for water, flooding.

If the light has water in it then show the customer that the light is now flooded.

and they will be billed the \$20 service fee. *(drying, cleaning and lubricating)*

If the light is flooded- remove the battery and set it aside,

Keep the light open to allow it to dry out.

(Replacement cost for a lost or missing light is \$50.00)

Putting the lights back in Storage:

Use the battery charger to charge up the used battery.

Insure all four parts of the Dive Light are accounted for:

(Lense Cap, Lamp Head, Light Body and Cord)

Place **dry** Dive Light parts in the storage box.

**** DO NOT SCREW THE LENSE CAP BACK ON ****

(By keeping the lense cap off, the 'O' rings will not deform under pressure)

After the battery has been charged- Return it and the charger to the storage box also.